



Product Specifications:

Material: Silicone
Size: H: 128mm W: D: 21.58mm
Battery: 240mA
Voltage: 3.7V
Number of Vibrations: 7 Speeds
User time: 2.5-3hours.
Sound Level: mid



CHARGING INSTRUCTIONS

Vibrator comes partially charged at about 50%, but it is not necessary to charge before use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input. The toy operates at 3.7 volts.

Initial charge takes about 70 minutes to complete, and subsequent charges also take about 70 minutes.

The light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging.

Charge lasts for 2.5 hours of play time at the highest setting, and about 3 hours at lower settings.

This toy has 7 speed and vibration functions.

Toy vibration strength will weaken as battery power depletes. Toy will operate for about ten minutes at weak power before depleting completely.

