

PRODUCT SPECIFICATIONS:	
MATERIAL: SILICONE & ABS	
FUNCTIONS: 9 POWERFUL VIBRATING SPEEDS & FUNCTIONS	
BATTERY: LITHIUM-ION	VOLTAGE: 3.7 V
USER TIME: 55 – 80 MINUTES	SOUND LEVEL: < 60 DB



**CHARGING INSTRUCTIONS:** It is not necessary to charge this toy before first use. To charge, connect the USB plug into a power source and the DC charger end onto the magnetic charging pins at the toy's base. A digital battery level display shows charging progress. Initial charge will take about 2 hours to complete; subsequent charges about 90 minutes. Battery charge lasts for about 80 minutes at the lowest power level and about 55 minutes at the highest. This toy operates at a sound level of less than 60db with a lithium battery at a voltage of 3.7V.

**INSTRUCTIONS FOR USE**

1. The control button is located at the front of the toy's base, above the hard-shell digital display.
2. Press the button for 3 seconds to turn toy on. The digital display will light up and show Mode: 0.
3. Press the button again more quickly to cycle through 9 speeds and patterns of vibration. Each number will appear in the digital display.
4. To turn toy off, press button for 3 seconds. The digital display will turn off and all vibration will cease.

- VIBRATOR CARE INSTRUCTIONS**
1. Compatible with Zero Tolerance – Lubricants as well as other water-based lubricants. Make sure lubricants do not enter the battery compartment, as they may react with the batteries.
  2. Continuous constant use of the vibrator's motor may create excessive heat. If your vibrator feels too hot, switch it off and allow it to cool before continuing use.
  3. Clean your vibrator after every use with Zero Tolerance – Clean: Foaming Toy Cleaner and a warm water rinse. Dry thoroughly before storage.
  4. Store your vibrator in a cool, dry place separated from other toys, as toy materials sometimes react chemically with each other.

