

 <http://www.evolvednovelties.com/>

**EVOLVED**  
*Love is Back*



#### Product Specifications:

Material: Silicone, ABS plastic

Battery: LiCoMnNiO<sub>2</sub>

Voltage: 3.7-4.2 V

Number of functions: 10

Vibration & 3 Sucking

User time: 60-80 MINS

Sound Level: ≤60dB/10cm

#### CHARGING INSTRUCTIONS

This vibrator arrives with high partial charge, so it is recommended to charge for about 30 minutes before first use. It is not necessary to fully charge toy before first use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input, located at the back of the handle base, above the suction cavity.

Initial charge should be at least 30 minutes, and subsequent charges will take about 2 hours to complete.

The indicator light will flash while device is charging and turn solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 80 minutes of play time on the lowest level of vibration, and about 60 minutes on the highest level.

This toy operates at a sound level of about 60db with lithium battery at a voltage of 3.7 - 4.2V.

#### INSTRUCTIONS FOR USE

This triple stimulation vibrator is operated with an easy-to-use 3-button panel located on the front of the main shaft. Each button controls a separate motor with its own on/off function.

The top button controls the vibration motor in the main shaft. Press for at least three seconds to engage the motor (LED light will go on) and click again more quickly to cycle through a total of ten vibration speeds and functions. Press again for at least three seconds to turn off the vibrations in the main shaft.

The middle button controls the rabbit stimulator shaft. Press for at least three seconds to engage the motor (LED light will go on) and click again more quickly to cycle through a total of ten vibration speeds & functions. Press again for at least three seconds to turn off vibrations in the rabbit stimulator shaft.

The bottom button controls the suction motor at the back of the handle base. Press for at least three seconds to engage suction function (LED light will go on) and click again more quickly to cycle through a total of three suction speeds. Press again for at least three seconds to turn off suction motor.

An air escape hole at the very base of the handle expels air from the suction motor. Please note that suction cannot work properly if this hole is covered.

