

Product Specifications:

Category: Vibrator Material: Silicone ABS+TPE+Silicone Finish: Silicone Size: H:39.5mm W:38mm L:190mm Battery: Lithium battery Voltage: 5V Number of Vibrations: 12 models User time: About 55 munites Sound Level: Less than 60DB

CHARGING INSTRUCTIONS
This vibrator arrives partially charged, so it is recommended to fully charge before use.
Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.
Initial charge will take about 3 hours, and subsequent charges will take about 1-2 hours to complete.

complete.
The LED light will flash while device is charging, The LED light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time. Charge lasts for about 70 minutes of play time on the lowest vibration level, and about 40 minutes of play time on the highest level. Toy vibration slows before stopping completely when charge is fully depleted. This toy operates at a sound level of 60db and a power level of 5V.

INSTRUCTIONS FOR USE

Turn the toy on by pressing the Power Button for at least 3 seconds.

Use the Power Button to cycle through the motor's 10 speeds and functions.

Press the Arrow button for 2 seconds to enable the Turbo Boost, which will last for 10 seconds before returning to the most recently used speed or function. Turn the toy off by pressing the Power Button

for at least 3 seconds.

