

## **Product Specifications:**

Category: Vibrator
User: Women
Material: Silicone +ABS
Finish: PU coating
Size: H: 85mm W: 35mm D: 25mm
Battery: Li-ion Battery
Voltage: 170mAh
Number of Vibrations: 1PCS
User time: 100mins
Sound Level: : 52dBA test
condition: in 40DB room, vibrator is
15CM far away from decibel meter.

CHARGING INSTRUCTIONS - This vibrator arrives partially charged at about 30%, and it is recommended to fully deplete the charge before recharging the battery. For longer battery life, make sure the first three charges complete to full battery capacity.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.

Initial charge will take about 80 minutes, and subsequent charges will also take about 80 minutes to complete.

The indicator light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 160 minutes of play time at the lowest level of vibration, and about 100 minutes at the highest level.

Toy vibration slows before stopping completely when charge is fully depleted.

This toy comes with a lithium battery (170mAh) and operates at a voltage level of DC3.7V.

This toy operates at less than 52db

INSTRUCTIONS FOR USE - This toy has a simple one-button control.

To turn toy on, press the button for at least 3 seconds. The toy will start at the lowest level of vibration. Press the button quickly to cycle through 20 speeds and functions.

This toy has a memory function for the course of one battery charge. Upon turning off the toy, it will remember the last vibration function and resume that function when it is turned on again. However, the memory is reset when you recharge the battery.

To turn toy off, press button for at least 3 seconds.